

READ ENTIRE MANUAL BEFORE OPERATION to ensure proper use and care of your new Lezyne Power Pack.



# Warnings Lezyne power packs have a water resistance rating of IPX7 under IEC standard 60529. Submerging the device is not

DO NOT ATTEMPT TO REMOVE ELECTRONICS. Doing so will void the warranty. Lezyne USA, Inc. does not accept any liability for injuries or other damages resulting from the improper use or improper

installation of this product in any circumstance.

recommended. If moisture does enter casing, Do not turn on, air out until completely dry.

Warranty


### Lezyne Batteries carry a six (6) month warranty from the original purchase date. Lezyne warranties cover any manufacturing $defects \ in \ materials \ or \ workmanship. \ Is sues \ not \ covered \ under \ warranty \ include \ normal \ wear \ \& \ tear, improper \ installation,$


attempting to access or modify electronics, damage or failure due to accidents, misuse, abuse and/or neglect. For all warranty issues worldwide, please contact the retailer that sold the product. For warranty queries contact: warranty@lezyne.com

Mounting

For proper mounting ensure rubber pads are in contact with frame. Then fasten the Velcro strap firmly.

**INFINITE LIGHT POWER PACK+** INFINITE LIGHT POWER PACK XL+





### 1. Open LED light USB seal. 2. Insert Infinite Light Power Pack USB-C power cable into LED light USB-C port.

## light will illuminate (showing battery status) and LED light power button will start flashing blue (HE charging mode). When Infinite Light Power Pack is not in use, hold Infinite Light Power Pack power button for 3 seconds to POWER OFF, or disconnect USB-C cable to POWER OFF. (When Infinite Light Power Pack powers off, LED power button will stop flashing, Infinite Light Power Pack indicator light will turn off)


**INFINITE LIGHT POWER PACK XL+** 

- NOTE: Infinite Light Power Pack will not automatically turn LED light ON/OFF, hold LED power button to power LED light
  - ON/OFF. • Do not insert Infinite Light Power Pack USB-C power output cable into power outlets/charging ports or into Infinite Light Power Pack USB-C port. See information below for Infinite Light Power Pack charging instructions.

3. The Infinite Light Power Pack will automatically power on when connected to the light: Infinite Light Power Pack indicator

(4) ON / OFF: hold 3 sec.

indicator light



THERMAL PROTECTION: Power packs have built in thermal control, if used in overly hot environments the pack will disable

# 2. Hold Power Pack XL power button for 3 seconds to POWER ON: Power Pack XL indicator light will illuminate (showing battery status) and LED will POWER ON. 3. When LED light is not in use, hold Power Pack XL power button for 3 seconds to POWER OFF (When Power Pack XL is powered off, LED light will POWER OFF, Power Pack XL indicator light will turn off)

**COMPATIBLE LEDS:** 

**POWER PACK XL** 

output until temperatures return to normal.

1. Connect Power Pack XL DC Jack to LED DC Jack.

(1)

SUPER HB STVZO P1350+, MEGA HB STVZO P2600,


NOTE: • Power Pack XL power button is used to power LED light OFF/ON.

(2)(3) ON / OFF: hold 3 sec.

indicator light

(1) NOTE: LED light is not included in this product.

(When powered off, click to check battery status.)



If power button does not flash when plugged in, selected USB port may not be powered—try another USB port.

# Power Pack will be fully charged when power button illuminates solid green (standard charging), 4.Remove Power Pack from charger and reinstall the USB seal—ensure USB seal is fully installed for water resistance.

Charging

**Fully Charged** 

Before using your Lezyne Power Pack for the first time, fully charge battery. Ensure Power Pack output cable is unplugged from LED light.

 ${\bf 2.Insert\ the\ USB-C\ charging\ cable\ into\ the\ Power\ Pack\ charging\ port.}$ 

3.Once charging, power button will flash blue or green depending on power source.

1.Open the USB seal on the Power Pack.

Illuminates green Flashes green USB-C Cable Not Included

Model

Charging

>10W

OWER ACK XL		INFINITE LIGHT POW PACK+ XI	INFINITE LIGHT POWER PACK+		
l∼6hr	S	3~6hrs		2~5hrs	
~13hrs		11~13hrs		7~9hrs	
E VER KL		NFINITE HT POWER PACK+			

Charging		OVV		11~131	IIS	11~131118		7~	SIIIS
Model		LIGI		NFINITE HT POWER ACK+ XL	LIGH	NFINITE HT POWER PACK+			
Cell Capacity	3,3	00 mAh	13,2	200 mAh	7,6	00 mAh			
Pack Capacity	4	8 Wh	4	8 Wh	2	8 Wh			

USB-C 18W Max

USB-C 18W Max

P

P

3

Output Charge Compatible

CORPORATE HQ

Reno. NV 89511

Lezyne USA, Inc. 5470 Kietzke Lane, Suite 300

Charging time

High Efficiency (HE Charging

Standard

**More Information** For more information on Lezyne products, visit: www.lezyne.com

DC JACK PLUG, 35cm Cable Lengt 14.8V

74670-EMANUAL FOR Y18 POWER PACK XL-INFINITE LIGHT POWER PACK+XL-EN-R0A1

Charging

Flashes blue

**Fully Charged** 

Illuminates blue

High Efficiency (HE) charging

CALIFORNIA OFFICE

645 Tank Farm Rd.